

Projector Things

When to Use Macros:

- Screen Up/Down: self-explanatory, use when you need to move the screen
- Projector On/Off: same, use when you need to turn the projector on/off
- Projector Off and Screen Up: Use at the end of an event to save having to push an extra button
- Projector On and Screen Down: Use at the beginning of the event

Macros:

- Screen Down/Up: makes the projector screen go down/up. If it is not working, you should find the remote (picture) in the drawer at FOH and click that. It is a finicky thing at best, so waving your arm around and walking up and down the aisles while clicking the button will usually let you find somewhere that it works
- Projector On/Off: turns the projector on/off. If it is not working, go to Benson Links and choose "Organ Projector" (picture) and then turn it on/off (standby) from there (picture)
- Projector Off and Screen Up: just a group of the two macros
- Projector On and Screen Down: just a group of the two macros

Revision #2

Created 24 January 2025 03:41:17 by Averie

Updated 29 April 2025 18:23:18 by Averie